# SANI-LAV COLUMBIA PRODUCTS

## **Large-Sized Industrial Nozzles with Brass Body**

Model N820 Series



#### **N820 Series Universal Features**

- · Heavy-duty brass body with brass and stainless steel components
- · Insulated rubber cover with yellow arrow directions
- · Safety shut off trigger when released
- · 3/4" GHT inlet allows direct hose connection
- · Swivel Adapter N17 and N20 (Sold Separately)
- · Replacement parts available
- · Maximum operating temperature: 200°F/93°C
- · Maximum working pressure 150 psi
- · Weight 2.3 lb.
- · Dimensions: L 5.04" x H 5.24" x W 1.71"

#### **Models**

Color	Standard	Low-Flow
Safety Orange	N820	N8120
Black	N8B20	N81B20
White	N8W20	N81W20
Red	N8R20	N81R20

## **Quick Specs**


Max Temperature	200°F/93°C
Max Pressure	150 psi
Inlet	3/4" Female GHT
Tip	Not Threaded
Body Material	Brass
Handle Type	Stainless Steel
Weight	2.3 lbs.
Hose Adapter	Model N20 (Included)
Dimensions	L 5.04" x H 5.24" x W 1.71"

## **Water Flow Rate Comparison**

PSI	Standard GPM	Low-Flow GPM	Water Saving
30	3.7	2.2	40.52%
40	4.2	2.4	42.50%
50	4.7	2.7	41.94%
60	5.4	3.0	44.44%
70	6.3	3.8	39.20%
80	6.8	4.2	38.24%
90	7.2	4.5	37.50%
100	7.9	4.8	39.24%



 $\label{thm:control} \textit{Variable Spray Nozzle} - \textit{trigger lever controls variable spray patern}.$ 



COLUMBIA SPECIFICATIONS NOZZLES

#### **N820 Replacement Parts**

Description	Part Number
Orange Insolated Cover	A N80C
Black Insolated Cover	■ N8BC
White Insolated Cover	© N8WC
Red Insolated Cover	■ N8RC
Brass Main Body	<b>■</b> N8MB
Handle Replacement Kit	<b>■</b> N8HR
Barrel Cartridge Replacement Kit	<b>G</b> N8BR
Barrel Cartridge Replacement Kit	₩ N8BR1
Bolt Sleeve	■ N8E
Locking Nut	■ N8F
















#### **Barrel cartridge replacement kit Instructions**

- 1. Pull cover  $\boxed{\textbf{A}}$  over the back of nozzle to expose the back end.
- 2. Take handle off nozzle by removing parts  $\boxed{\mathbf{1}}$ ,  $\boxed{\mathbf{2}}$ , and  $\boxed{\mathbf{3}}$ .
- 3. Unscrew part  ${
  m J}$  locking nut and remove bolt sleeve  ${
  m I}$  and the cartridge  ${
  m G}$  or  ${
  m II}$  .
- 4. Insert the new cartridge.
- 5. Re-Install the handle.
- 6. Replace the sleeve with the open end facing down.
- 5. Screw the locking nut back into place.
- 6. Slip the cover back over the nozzle end using a round ended tool similar to a shoe horn.

COLUMBIA PRODUCTS

800.626.2117 • columbiasinks.com • info@columbiasinks.com